

legrand / Pass & Seymour

Replacement Component Instructions for 30, 60 and 100 Ampere Manual Motor Controller / Disconnect Switch

**WARNING - Risk of Fire or Electric Shock. Use Replacement Components only with
Pass & Seymour Manual Motor Controllers as indicated in table below.**

Refer to Disconnect Switch Instruction Sheet (p/n 340987) for specific wiring instructions.

Replacement Comp. P/N	Description	Use Only with P&S Cat. Nos.
PS30SSRC	PS30SS cover assembly	PS30SS
PS60SSRC	PS60SS cover assembly	PS60SS
PS100SSRC	PS100SS cover assembly	PS100SS
PS30SSAXRC	PS30SSAX cover assembly	PS30SSAX
PS60SSAXRC	PS60SSAX cover assembly	PS60SSAX
PS100SSAXRC	PS100SSAX cover assembly	PS100SSAX
PS30RGB	30A ground terminal	PS30SS, PS30SSAX
PS60RGB	60A ground terminal	PS60SS, PS60SSAX
PS100RGB	100A ground terminal	PS100SS, PS100SSAX
PS30RNB	30A neutral terminal	PS30SS, PS30SSAX
PS60RNB	60A neutral terminal	PS60SS, PS60SSAX
PS100RNB	100A neutral terminal	PS100SS, PS100SSAX
RS30	K&N switch for 30A, no aux	PS30SS
RS60	K&N switch for 60A, no aux	PS60SS
RS100	K&N switch for 100A, no aux	PS100SS
RS30AX	K&N switch for 30A, w/ aux	PS30SSAX
RS60AX	K&N switch for 60A, w/ aux	PS60SSAX
RS100AX	K&N switch for 100A, w/ aux	PS100SSAX
SSMF	feet for 30A	PS30SS, PS30SSAX
SSMF60	feet for 60A, 100A	PS60SS, PS60SSAX, PS100SS, PS100SSAX